

AIRBORNE RADAR APPROACH DESCENT TEMPLATE

AIRFIELD _____	MDA _____	PATTERN ALT. _____
FLD ELEV. _____		HAT. _____

DIST	GLIDESLOPE				FLD ELEV	APPROACH ALT.			DIST
	0 4	0 3.5	0 3	0 2.5					
10	4250	3720	3190	1660					10
9	3820	3350	2870	2390					9
8	3400	2970	2550	2130					8
7	2970	2600	2230	1860					7
6	2550	2230	1910	1600					6
5	2130	1860	1600	1330					5
4	1700	1490	1280	1070					4
3	1280	1120	960	800					3
2.5	1060	930	800	670					2.5
2.0	850	750	640	530					2.0
1.5	640	560	480	400					1.5
1.0	430	380	320	270					1.0
.5	220	190	160	140					.5

Rate of Descent

GS/KTS	100	105	110	115	120	125	130	135	140	145	150	155	160
0 2.5	442	464	486	508	531	553	575	597	619	641	663	685	707
0 3.0	531	557	584	610	637	663	690	716	743	770	796	823	849
0 3.5	619	650	681	712	743	774	805	836	867	898	929	960	991
0 4.0	708	743	779	814	850	885	921	956	991	1027	1062	1098	1135

**Download any U.S. FedForm (free, fillable, savable in Adobe Reader)!
Start with the "Flash Demo" at the top of the following page:
www.usa-federal-forms.com**

**Convert any fillable PDF form to savable (locally, in Adobe Reader):
www.savePDF.com**

**Convert any document (in any format) to PDF fillable and savable:
www.FillinDocs.com**

**All (10's of 1,000's) U.S. Federal Forms already fillable, savable:
www.usa-federal-forms.com**

About the ITAOP/savePDF Method

The traditional Field-by-Field creation process is extremely ineffective and slow.

The only realistic option to create high-quality forms is the Insert-Text-Anywhere-on-Page (ITAOP) method.

The field creation process is about 10,000 times faster than the traditional method; the list of ITAOP features is not even available for the traditional method.

ITAOP savePDF method proved to be very simple and completely reliable for millions of users all over the world (incl. individuals, companies, organizations, government employees).